

Mini 360 Degree Continuous Servo Code

Continuous servos have a different structure to them than regular servos.

A regular servo simply goes to a degree angle to tell it, where as continuous servos of course keep going around, so we must program them slightly differently, like so:

```
// Include the servo library

#include <Servo.h>

// Create the servo object

Servo myservo;

// Setup

void setup() {

  myservo.attach(9); // attach the servo to our servo object

  myservo.write(90); // stop the motor

}

// Main loop

void loop() {

  myservo.write(45); // rotate the motor counter-clockwise

  delay(5000); // keeps rotating for 5000 milliseconds (5 seconds)


  myservo.write(90); // stop the motor

  delay(5000); // stay stopped
```

```
myservo.write(135); // rotate the motor clockwise
```

```
delay(5000); // keeps rotating
```

```
}
```



Revision #2

Created 19 October 2023 11:47:00 by Matt Jarvis

Updated 29 April 2024 22:24:58 by Tom Lynch